




HEIN-WERNER MODEL K

J-1 Lifting Arm, W/J-198, J-200
 J-2 Body for Unit
 K-3 Saddle Holder with 2-K-30
 K-4 Rear Wheel (for Caster)
 K-5 Caster Fork, 2-G-119, K-93
 K-6-A Caster Bracket, 2-K-234, K-83-A
 K-7 Handle Fork
 J-9-A Ram Complete, J-724-1, J-720
 L-14-A Front Wheel, each
 GG-15 Release Knob, only
 H-16 Quadrant Lever, J-54
 J-17-A Pull Back Spring, each
 W-21-B 11/16" Pump Cup Assembly
 J-22 Pump Packing (Set of 4), J-254
 H-24 Spring for Control
 J-25 Front Axle, 2-J-190, 2-J-82, 2-J-36
 J-26 Bushing for Front Axle
 K-27 Rollers for Front Wheels, Set of 32
 K-28 Saddle with K-229
 K-30 Saddle, Pin, each
 J-31 Parallel Link, J-33, each
 J-32 Parallel Link Pin, 2-G-119
 J-33 Parallel Link Stud
 J-36 Rivet for J-25
 J-37-A Main Pin, Nuts and Washers
 J-39-A Handle Bolt, K-421 Spacer
 K-40 Side Bar, R. H., J-33, J-26
 K-41 Side Bar, L. H., J-33, J-26
 J-42 Outside Tube, 4" Long
 J-42-B Outside Tube, 4 3/4" Long
 J-43 Ram Cylinder
 J-44-B Cylinder End Nut
 J-45-A Ram Packing Nut
 J-46 Packing Nut Washer
 J-48 11/16" Pump Piston, Complete
 J-48 11/16" Pump Piston, Only
 J-50 Pump Links, Set of 2
 G-51-A Pump Link Pins with Clips, Set
 G-52 Quadrant Lock Pin Assy
 J-55 11/16" Pump Packing Gland
 K-72 Pipe Lever 48 1/2" with Grip
 K-75 Quadrant Control Rod, G-73, G-79
 G-78-A Control Knob, G-97 and Washer
 J-82 Washer for J-25
 K-83-A Stud for Caster

J-87-2 Release Valve N.S
 J-87-A Release Valve
 K-91 Release Rod (Square) 46 3/8" Long
 K-93 Caster Axle, 2-G-119
 J-113-A 3/4 x 7/8" Cap Screw and Washer
 G-119 Clip, each
 J-132 End Cover, 138-A, 139-3
 J-133 Valve Lever with H-163
 J-134 Push Lever with H-162
 J-136 Release Valve Spring
 138-A Filler Screw, 139-3 Washer
 H-143 Trunnion Stud Assy
 H-148 Release Valve Packing (Set of 7)
 J-149-1 Pump Cylinder
 J-190 Snap Ring, each for J-25
 J-196 Spring Bar Assy
 J-198 Drag Links, Set of 2, J-200, J-199A
 J-199-A Drag Link Stud
 J-200 Cross Pin
 J-211 Packing Box
 J-218 Strut with Cap Screws
 K-234 Cap Screw for Caster
 J-259 Release Valve Bolt Assy
 G-276 Bolt with Nut and Washer
 H-277 9/16 x 2 3/4" Bolt with Nut
 J-343 Nut for Ram Cup
 385 Pump Valve Seal
 K-421 Spacer for Handle Fork
 522-1 Washer for Ram Cup
 J-720 Ram Spacer
 J-724-1 Ram Cup Leather, 1 3/4", Dia.
 734 Ram Packing, Set of 3
 K Safety Valve Complete
 K Pump Valve Complete
 K Caster Complete
 K Ball Bearings for Caster, Set of 32
 K Handle Complete
 Hydraulic Jack Oil (Quart)

ADDITIONAL PARTS FOR EARLY MODEL "K"

G-8-1 Handle Grip, G-111, G-245
 G-15-3 Release Knob, J-91 Rod
 J-18 Ram Packing, Set of 3
 J-72 Handle Pipe only 44 1/2" Long
 J-75-A Quadrant Rod, G-73, 45-3/16" Long
 J-149 Pump Cylinder
 J-283 Fiber Backing Washer



HEIN-WERNER MODEL "K" HYDRAULIC JACK UNIT

